

Brake Light Switch - Brake Pedal, 400cc - 10A8817 - PBC2071F1



Rating: Not Rated Yet

Price

\$18.64

[Ask a question about this product](#)

Description

Rear brake cable switch used to activate brake lights. This brake light switch is most commonly (but not exclusively) used for 400cc ATVs and UTVs from companies like Odes and Liangzi.

Common Liangzi model names consist of variations of "Liangzi 400cc ATV", "Liangzi 400cc UTV", "Liangzi 400cc XUV", "Liangzi 400cc 4x4", "Liangzi LZ400", "Liangzi LZ400-4", Liangzi LZ400-C etc. Listed Liangzi foot brake light switch part number is 04-0905000 and listed on the factory parts list as "Footbrake switch".

Common Odes model names consist of variations of "Odes 400cc ATV", "Odes 400cc UTV", "Odes 400cc XUV", "Odes 400cc 4x4" etc.
Common listed Odes foot brake light switch part number is 04-0905000 and listed on the factory parts list as "Footbrake switch".